



1343 digits Operation instruction



A. Features

- ◆ Time, Alarm, Stopwatch, Dual time, Countdown.
- ◆ Date, Month, Day, Hour, Minute, Second.
- ◆ Daily Alarm.
- ◆ Chime hourly.
- ◆ Stopwatch: the maximum display range of stopwatch is 99 hours, 59 minutes, 59 seconds 99.
- ◆ Timer: the maximum display range of countdown timer is 24 hours.
- ◆ 12 / 24H format.
- ◆ EL backlight for 3 seconds.

B. Operation Manual



1. At normal mode, press B key to select operation mode. Press A key EL illuminates for 3 seconds.
2. Timing Function
 - ◆ At normal mode, press and hold C key for 2 seconds to time setting, and “Second” flashing, press D key to zero. Press B key to select item as following sequence:
Second-Minute-Hour-12H/24H-Month-Day-Week
 - ◆ Press D key to select the flashing item, press and hold on D key to increase the flashing item quickly .
 - ◆ Press C key to exit.
 - ◆ When setting the “seconds”, the seconds are in the range of 30 to 59, resetting them to 00 and adding 1 to the minutes. While the seconds are in the range of 00 to 29, the minutes won't be changed.
3. Daily Alarm
 - ◆ At alarm mode, press and hold C key for 3 seconds and “Hour” flashing into time setting. Press B key to select item as following sequence: Hour-Minute
 - ◆ Press D key to adjust the flashing item, press and hold on D key to increase the flashing item quickly . Press C key to exit.
 - ◆ At the alarm mode, press D Key to open or close the alarm “ALM” and the hourly chime “CHI”.
 - ◆ When the Alarm function chiming, the symbol will flashing and chiming for 20 seconds, press any key to stop.
 - ◆ Hourly chiming for once when on time alarm.

4. Stopwatch Function

- ◆ Stopwatch: maximum in 23 hours 59 minutes 59 seconds, will restart when arrive at maximum. The hour display at date zone.
- ◆ Press D key to Start/Stop running; press C key to zero when stop.
- ◆ When running, press C key to split Counting. Then press C key to record the first timing, and stop counting; When press C key to start running, press D key to record the second timing, and press C key to zero.

5. Dual Time Function

- ◆ Press D key to dual time mode. Press and hold C key for 2 seconds to select "Minute" setting, and "Minute" flashing. Press B key to select "Hour" setting.
- ◆ Press D key to adjust the flashing item,press and hold on D key to increase the flashing item quickly .
- ◆ Press C key again to finish setting, and return to Dual Time displaying mode.
Remarks: Without second setting at this mode.

6. Countdown Function

- ◆ Press B key for 3 times to countdown function, maximum at 24 hours.
- ◆ When count to 0:00' 00" , chiming for 12 seconds. During the chiming, press any key to stop.
- ◆ At countdown mode, press and hold C key for 2 seconds and “Hour” flashing to countdown setting. Press B key to select item as following sequence: Hour-Minute
- ◆ Press D key to adjust the flashing item,press and hold on D key to increase the flashing item quickly .
- ◆ Press C key to exit and press D key to start countdown.