
# **8 digital Operation Manul**



#### A . Features


- > 8 Digits LCD Display, Display Hour, Minute, Second, Month, Day and Week
- 2 Alarm and Chime hourly
- Dual Time
- Timer
- > 12 / 24H format selectable
- ➤ 1/100 second Chronograph with split functions
- EL backlight

# **B**. Operational Manual



### 1. Real Time

- > Use the Real Time Mode to set and view the current time and date.
- In the Real Time Mode. Press D key to view the current date, Release D key will return the Real Time Mode
- To set the time and date:
  - a). In the Real Time Mode. Press C key until the "Seconds" start to flash, which indicates the setting screen.
  - b). Press B key to move the flashing in the sequence shown below to select other settings shown.



c). When the setting you want to change is flashing, press D key to change it as described below.

change this setting	Perform this button operation
Seconds	Press D key to reset to <b>00</b> .
Minutes, Hour, Week, Month, Day	Press D key to increase the setting
12/24Hour	Press D key to change the 12-hour format or 24-hour format

d). The day of the week is automatically displayed in accordance with the date (year, month, and day) settings.


## 2. Chronograph

➤ The display range of the Chronograph is23hour,59 minutes, 59.99seconds...

# **8 digital Operation Manul**

The stopwatch will be count to max. values and restart from zero until you stop it.

To measure times with the stopwatch



## 3. Daily Alarm

- Alarm Operation: The alarm tone sounds at the preset time for about 15 seconds. Pressing any button stops the alarm tone operation.
- Turn On / Off Alarm and Chime
  Press D key to turn on/off Alarm (" ") or Chime (" ").
- Alarm setting: In the Alarm Mode, press C key until the Hour setting of the alarm time starts to flash, Press B key to select "Hour", "Minute "or "alarm1/alarm2" setting, Press D key to adjust the flashing item, Press C key to confirm.

## 4. Countdown Timer

- ➤ The display range of the timer is 23hr 59min,59sec.
- Finer alarm sounds for about 10 seconds when counting down to 0:00:00.
- ➤ Timer Time setting

Press and hold C key f to time setting state and "Hour" flashing, Press B key to select "Hour" or "Minute" setting, Press D key to adjust the flashing item, Press C key to complete setting.

> Timer operation

Press D key to Start/Stop counting.

### 5. Dual Time

> Dual Time setting

In the Dual Time mode ,Press and hold C key to select "hour" setting, Press D key to adjust the flashing item, Press C key again to finish setting ,and return to Dual Time displaying mode .

# C. Specifications

➤ Module Size

Module Thickness

Operational Temperature Range

: Ф36.2mm

: 9.30mm

: 0°C~50°C

: 3.0V

:  $\pm 90 \text{sec/month}$ 

: CR2025 (content: 170mAh)

 $\leq 3.5 \text{u A}(T=25^{\circ}\text{C})$ 

# **8 digital Operation Manul**

- Operational Voltage
- Accuracy
- > Battery Code
- Current Consumption for Digit (maxima)
   Current Consumption for Digit (averagely)
- > Alarm Current
- > EL Current
- ➤ Battery life 2 backlight operation (6 seconds) per day 20 seconds of alarm operation per day