


# 时刻美 10 个字电子手表说明书




## 功能简介:

- ◆ 10位计时功能, 显示时、分、秒、日、星期。
- ◆ 12/24 时制选择, 全自动日历
- ◆ EL 背光
- ◆ 响闹及整点报时
- ◆ 1/100秒秒表及分段计时

## 产品功能模式:

- ◆ 任何模式下, 按A键EL亮三秒
- ◆ 正常模式下, 按D键转换12/24时制
- ◆ 正常模式下, 按B键模式转换如下:




## 响闹模式:

- ◆ 在正常显示模式下按B一次进入响闹时间设置模式。
- ◆ 按C响闹小时设置且小时将会闪动, 按D改变响闹小时。
- ◆ 再次按C进入响闹分钟设置且分钟将会闪动, 按D改变响闹分钟。
- ◆ 按B退出响闹时间设置模式返回正常显示模式。

## 响闹与整点报时开关设置:

- ◆ 在正常显示模式下按B一次进入响闹模式, 按D进行响闹/整点报时转换及开/关设置。
- ◆ 只出现“AL” /ALM 图标, 则表示响闹为开; 只出现“CH” /CHI 图标, 则表示整点报时为开; 图标都显示, 则表示响闹与整点报时都为开; 图标都不出现则都为关。

## 跑秒模式:




## 时间与日历模式:

- ◆ 在正常显示模式下按B三次进入时间与日历设置模式并且秒钟将闪动, 按D归零;
- ◆ 按C进入小时设置且小时将会闪动, 按D改变小时。
- ◆ 再次按C进入分钟设置且分钟将会闪动, 按D改变分钟。
- ◆ 按C第三次将进入月份设置且月份将会闪动, 按D改变月份。
- ◆ 按C第四次将进入日期设置且日期将会闪动, 按D改变日期。
- ◆ 按C第五次将进入星期设置且星期将会闪动, 按D改变星期。
- ◆ 按B退出时间与日历设置模式并且返回正常显示模式。

**注意事项: 在游泳或洗车时, 可以使用本表, 但不能在水中操作按钮。**

# Skmei 10 Digits Digital Watch Instruction




## A. Features:

- ◆ 10 Digits LCD Display, Display Hour, Minute, Second, Day and Week
- ◆ Chime hourly and Daily Alarm
- ◆ 12 / 24H format selectable, Auto Calendar
- ◆ 1/100 second Chronograph with split functions
- ◆ EL backlight

## B. Operational Manual:

- ◆ At any state, press A key EL backlight for 3s.
- ◆ In normal display Mode, Press D key to convert 12/24H
- ◆ Press B key to convert mode:



## Alarm Setting:


- ◆ in normal display Mode, press B key once enter into Alarm Mode
- ◆ Press C key the Hours will flash, Press D key to adjust the correct hour for your Alarm.
- ◆ Press C key the Minutes will flash. Press D key to adjust the correct minutes.
- ◆ Press B key to exit.

## Alarm & Chime ON/OFF:

- ◆ In normal mode press B key once enter into alarm mode, press D key to ON/OFF the Alarm&Chime function, Press B key to exit.
- ◆ If just appear the icon “AL” /ALM” means Alarm function ON, if just appear the “CH” /CHI” means Chime function ON, if the two icon all appear mean two function ON, other wise means OFF

## Chronograph functions:

- ◆ In normal display mode: press B key twice, enter Chronograph mode
- ◆ Press D to start, press D again to suspend, press D again to continue, press D to suspend again,.....when suspend, press C key back to 0:00:00.
- ◆ In Chronograph mode, press D key to start, press C key enter into split function, press C key again to get the first group record, but the second group still processing in the back ground, press C key again to continue the second group, press C key again to read the second group record,.....when the final group finished, Press D key to stop the SPL function, press C key read the final group(SUM) record, press C key again to clear the record to zero.



## Time & Date Setting:

- ◆ In normal Mode, press B key three times to enter setting mode and the seconds will flashing. Press D key to zero.
- ◆ Press C key the Hours will flash. Press D key to adjust correct Hours
- ◆ Press C key the Minute will flash. Press D key to adjust the correct Minutes.
- ◆ Press C key the Month will flash. Press D key to adjust correct Month
- ◆ Press C key the Date will flash. Press D key to adjust correct date
- ◆ Press C key the week will flash. Press D key to adjust the correct week.
- ◆ Press B key to exit.